
AD-1688 Specifications

Applicable devices	Balances and scales with an RS-232C connector manufactured by A&D	
Memory size	Approx. 5,000 data sets in the standard format (15 characters in 1 data set) can be stored	
Clock error	±1 minute / month	
Applicable OS	Windows 2000 / XP / Vista	
Dedicated power supply	Not required. Power is supplied by the weighing instrument or PC.	
Operating environment	5 °C to 40 °C (41 °F to 104 °F), 85 %RH or less (no condensation)	
Dimensions	55 × 103 × 16.5 mm	
Weight	Approx. 60 g	

Standard Accessories

USB extension cable (0.5 m)
Three RS-232C cables (1 m)
with a D-sub 9-pin connector
with a D-sub 25-pin connector
with a 7-pin DIN connector

The data is stored in CSV format and can be used easily by software such as Microsoft Excel.



Quick USB Adapter AID-8527

Transmits weighing data directly from an A&D balance or scale to a USB port of a PC (no driver software is required)*

Sends weighing data to software applications such as Microsoft Excel, Word, and Notepad

Small size and IP65 dust and waterproof (with the casing cover) *Only unidirectional communication from a balance or scale to a PC is possible.



Applicable devices	Balances and scales with an RS-232C connector manufactured by A&D
Dedicated power supply	Not required. Power is supplied by the weighing instrument or PC.
Operating environment	5 °C to 40 °C (41 °F to 104 °F), 85% RH or less (no condensation)
Dimensions	55 × 103 × 16.5 mm
Weight	Approx. 60 g
Standard accessories	USB extension cable (0.5 m), Three RS-232C cables (1 m)





Quick USB Adapter

AD-8527